

Overview of Select Screen and Switches

Switch operation

This system operates mainly by the navigation controller beside the parking brake lever. When you select a switch on the screen and push some buttons on the navigation controller, a beep sounds.

INFORMATION

- *You cannot operate dimmed switches.*
- *Wipe off fingerprints on the surface of the display using a glass cleaning cloth.*
- *The display may be tinged in purple due to the reflection of sunlight, but this is not a malfunction.*

Navigation display



Navigation controller




SSN/J182

Symbols and Switches

Symbols and Switches




Symbols and Switches




Changing the map direction

When the dual screen is displayed, the left screen can be switched to "North-up" / "Heading-up".




Display of Point of Interest

Symbols such as restaurants and hotels, etc. can be displayed on the screen. For details, see page 41.




Changing the route guidance

When you select this switch, the "Change Route" screen will appear. For details, see page 29.



Quick Registration of marked point

To register the current vehicle position as a marked point. For details, see page 71.



Changing the map direction on the right screen

When the map display is shown on the dual screens, select this to call out the editing menu (screen) on the right screen.



"Heading-up" symbol and scale of map

On the map, the vehicle travel direction is up. The red arrow indicates the north.